

Temporary Binders for Powder Shaping, Debinding and Sintering Research

Residual-binder, density, porosity and final-material validation without automatic biological transfer

Dr. Juan Segurola, founder and Scientific Director · 3Dresyns by Resyner Technologies S.L. · General Etxague 15B, 20003 Donostia / San Sebastián, Gipuzkoa, Spain · info@3dresyns.com · www.3Dresyns.com

Highlights

- Binders are temporary manufacturing constituents whose removal must meet final-material residual limits.
- Bio or aggregate ecological-safety language is not used as a substitute for composition and test evidence.
- Titanium and other biomedical geometries are research-manufacturing examples, not implant outcomes.
- Thermal, debinding and biodegradation values require exact method, test item and report.
- Final suitability depends on powder, binder removal, density, porosity, impurities and sintering.

Abstract

Temporary binders enable shaping of functional powders before debinding and sintering. Binder-level attributes do not transfer automatically to the final component.

Removal must be demonstrated to the residual limits required for the final material and use. Exact temperatures, degradation, melting or biodegradation claims require controlled reports.

Patient-specific implant positioning is removed. Titanium and other powder geometries remain research-manufacturing examples pending complete component and device validation.


Keywords binder · powder shaping · debinding · sintering · cold fusion · residual chemistry

Source use. Product evidence is in [1]; powder processing in [2–4]; biological scope and related binder control in [5–6].

1. Feedstock and green-part control

The record identifies functional powder, particle distribution, binder composition/loading, mixing, shaping and green strength.

- Control segregation and porosity.
- Record made-to-order formulation.
- Define green-part acceptance.



Release requires traceable evidence at every gate; a catalogue label cannot bypass the chain.

Figure 1. WP-38 evidence gates from controlled material description to final acceptance.

2. Debinding and sintering evidence

Removal is quantified through mass loss, residual carbon/chemistry, atmosphere and geometry. Sintering records density, porosity, impurities, dimensions and properties.

- Verify temperature claims.
- Challenge thick sections.
- Define residual and density limits.

3. Final-material boundary

A binder-level Bio, degradable or biological attribute does not establish the suitability of the sintered component, particularly for implants or regulated uses.

4. Minimum controlled evidence before release

Control field	Required record	Release interpretation
Feedstock	Powder, binder and loading	Catalogue description only until evidence is linked
Shaping	Process, geometry and green quality	Control process variables and change triggers
Debinding	Profile, atmosphere and residuals	Report method, result, uncertainty and limits
Sintering	Density, impurities, properties and use	Apply final acceptance and responsibility boundary



Description ≠ measured result ≠ certification or finished-device approval

Figure 2. WP-38 separates catalogue positioning, measured evidence and final application decisions.

KEY INSIGHT

Precise product or application language is retained only when the exact formulation, method, processed specimen and controlled evidence can be traced.

5. Limitations

- Aggregate ecological-safety and binder-level biological wording is removed.
- Implant outcomes are not claimed.
- Biodegradation needs method and pass criteria.
- Residual binder must be measured.
- Final component validation remains mandatory.

6. Conclusions

- Binders are temporary manufacturing constituents whose removal must meet final-material residual limits.
- Bio or aggregate ecological-safety language is not used as a substitute for composition and test evidence.
- Final suitability depends on powder, binder removal, density, porosity, impurities and sintering.
- This corrected candidate remains local and on HOLD until series-wide scientific, metadata and visual release checks are complete.

Revision note

Version 6.3 removes aggregate ecological-safety, binder-level biological and implant-platform claims and adds residual-binder, density, porosity, impurity and final-material gates.

Acknowledgements. The author acknowledges the 3Dresyns technical team and users whose manufacturing experience informed this correction.

Disclosure. Dr. Juan Segurola is founder and Scientific Director of 3Dresyns by Resyner Technologies S.L., the supplier of the materials discussed.

References

- [1] 3Dresyns. Current powder-binder TDS/SDS and controlled debinding/sintering reports.
- [2] German, R. M. (2014). Injection Molding of Metals and Ceramics.
- [3] ISO 22068:2021. Sintered-metal injection-moulded materials—Specifications.
- [4] ISO/ASTM 52900:2021. Additive manufacturing—Fundamentals and vocabulary.
- [5] ISO 10993-1:2025. Biological evaluation of medical devices—Part 1.
- [6] 3Dresyns WP-35. Photocurable Binder Materials for Lithography-Based Metal Manufacturing, corrected candidate.