

Triplet–Triplet-Annihilation Upconversion for Photopolymerisation: Sensitiser–Annihilator Pairs, Oxygen, Thresholds and Cure Depth

Engineering superlinear photochemical response without confusing photon upconversion with conventional multiphoton absorption

Juan Segurola

3Dresyns by Resyner Technologies S.L.

© 2026 Juan Segurola. All Rights Reserved.

Correspondence: info@3Dresyns.com · www.3Dresyns.com

ER-303 · Engineering Review · Version 0.5 · 28 September 2026

Abstract

Triplet-triplet annihilation upconversion (TTA-UC) can convert lower-energy illumination into higher-energy emission that drives photopolymerisation with a nonlinear intensity response. This creates opportunities for cure confinement, visible-light operation and lower-cost optical hardware, but the useful threshold depends on sensitiser-annihilator photophysics, oxygen quenching and initiator coupling. This review links those variables to cure depth, voxel confinement and process stability using high-resolution printing and DLP demonstrations.

Keywords: triplet-triplet annihilation; photon upconversion; photopolymerisation; oxygen; threshold response; cure depth

1. Significance and scope

Triplet-triplet-annihilation upconversion is relevant to photopolymerisation because it can convert lower-energy excitation into locally higher-energy emission, but only above a coupled photophysical threshold. The engineering question is whether sensitiser-annihilator transport, oxygen sensitivity and local photon density can produce a reproducible initiation field at useful depth. Proprietary formulations and machine-specific tuning rules are outside scope.

1.1 Corpus boundary

ER-303 owns triplet-triplet-annihilation upconversion as the photochemical source of higher-energy emission used to drive polymerisation. ER-304 owns inorganic upconverting nanoparticles; ER-332 owns multiphoton metasurface fabrication.

2. Mechanistic basis

A sensitiser absorbs the excitation photon, transfers triplet energy to an annihilator, and two triplet annihilators interact to populate a higher-energy singlet state. The resulting emission can activate a photoinitiator. Because two triplets participate, the upconverted output can be superlinear below saturation, producing a chemically useful intensity threshold [1,2].

3. State variables and process control

Oxygen competes strongly with triplet states and can suppress upconversion, although formulation strategies can enable operation under ambient conditions. Sensitiser and annihilator concentration, triplet lifetime, energy-transfer efficiency, excitation wavelength and initiator overlap must therefore be considered as one coupled photosystem rather than independently optimised additives [2].

4. Principal failure modes

Weak cure can arise from oxygen quenching, insufficient triplet population or poor spectral overlap with the initiator. Conversely, increasing sensitiser loading can increase self-absorption or optical attenuation. Apparent resolution gains should be separated from simple underexposure by comparing cure depth and lateral feature response across intensity and dose. [2]

5. Measurement architecture

Minimum evidence includes excitation and emission spectra, intensity-dependent upconversion response, oxygen-state declaration, cure-depth or conversion curves and printed feature metrology. Thermal measurements are useful where high local irradiance is used. Controls without the annihilator or sensitiser help distinguish true upconversion-mediated initiation from direct absorption. [1,2]

6. Evidence hierarchy and transfer

TTA photopolymerisation has enabled submicrometre printing with continuous visible illumination and DLP operation in ambient conditions. More recent vat studies show that the nonlinear photochemical response can increase curing contrast, but performance remains formulation-specific [1-3].

7. Qualification architecture

A TTA-upconversion qualification package should measure excitation irradiance, upconverted emission, oxygen state, conversion versus depth and the threshold relation between them. Controls should separate direct monomer or initiator excitation from upconversion-mediated cure and challenge changes in optical path length and oxygen ingress. Transfer requires preservation of the threshold margin and emission-to-conversion relation, not merely the same incident wavelength.

8. Interpretation and decision logic

Decision logic should separate insufficient triplet generation from oxygen quenching and poor overlap with the downstream initiator. The mechanism is supported when intensity-dependent upconversion, conversion and feature confinement change coherently under controlled oxygen and component-removal controls.

Table 1. Qualification matrix for triplet-triplet-annihilation upconversion for photopolymerisation.

State variable	Minimum evidence	Qualification purpose
Upconversion output	Emission versus excitation intensity	Defines nonlinear threshold
Oxygen state	Air/inert condition or dissolved O2 proxy	Bounds triplet quenching
Cure response	Conversion/cure depth versus intensity	Links photophysics to polymerisation
Feature fidelity	Lateral/vertical dimensions	Tests confinement

9. Diagnostic interpretation matrix

The diagnostic matrix should distinguish insufficient triplet population, oxygen quenching, annihilator or sensitiser imbalance, reabsorption losses and genuine upconversion-driven cure. Interpretation should link emission and conversion spatially so that deep cure is not attributed to TTA when direct excitation or heating could explain the result.

Table 2. Diagnostic interpretation matrix for triplet-upconversion cure behaviour.

Observed deviation	Competing mechanism	Discriminating check
No cure	Triplet quenching or poor overlap	Emission plus initiator spectrum
Deep overcure	Threshold saturation	Intensity-dependent cure curve
Colour/attenuation	Sensitiser absorption	Transmission spectrum
Heating	High local irradiance	Temperature measurement

10. Limitations and evidence gaps

The literature is still compact compared with conventional photoinitiation. Many reported systems use specialised chromophores, and photostability, colour, residual sensitiser and long-term material effects are incompletely standardised. Numerical thresholds should therefore be treated as system-specific.

11. Conclusions

TTA-UC is best treated as a nonlinear photosystem whose manufacturing value depends on controlled triplet kinetics and oxygen management. Qualification should demonstrate the causal chain from upconversion response to polymer conversion and finally to cure confinement.

References

1. Limberg DK, Kang J-H, Hayward RC. Triplet-Triplet Annihilation Photopolymerization for High-Resolution 3D Printing. *Journal of the American Chemical Society*. 2022;144(12):5226-5232. doi:10.1021/jacs.1c11022.
2. O'Dea CJ, Isokuortti J, Comer EE, Roberts ST, Page ZA. Triplet Upconversion under Ambient Conditions Enables Digital Light Processing 3D Printing. *ACS Central Science*. 2024;10(2):272-282. doi:10.1021/acscentsci.3c01263.
3. O'Dea CJ, Scruggs EP, Page ZA. Triplet-Triplet Annihilation Enhances Photochemical Curing Contrast for Vat-Based 3D Printing. *Advanced Functional Materials*. 2026;36(41):e30758. doi:10.1002/adfm.202530758.

Competing interests

The author is Founder, CEO and CTO of 3Dresyns by Resyner Technologies S.L. No comparative product recommendation is made.

Data availability

No new experimental dataset was generated for this review.